

Intramedullary Nail Removal Set

System designed to help remove an intramedullary nail



Stabilizing Bar
#2027-06



Open End Wrench
#2027-07

PRODUCT NO'S:	
2027-20	[Intramedullary Nail Removal Set]
2027-06	[Stabilizing Bar] Overall Length: 5.9" (15 cm)
2027-07	[Open End Wrench] Overall Length: 3.94" (10 cm)
2027-11A	[Extraction Spreader Size 1] Thread Diameter: 6-9 mm Overall Length: 2.75" (7 cm) <i>Two included in set; product number is for one only</i>
2027-11B	[Extraction Spreader Size 1.5] Thread Diameter: 8-10 mm Overall Length: 2.75" (7 cm) <i>Two included in set; product number is for one only</i>
2027-11C	[Extraction Spreader Size 2] Thread Diameter: 9-12 mm Overall Length: 2.75" (7 cm) <i>Two included in set; product number is for one only</i>
2027-11D	[Extraction Spreader Size 2.5] Thread Diameter: 11-13 mm Overall Length: 2.75" (7 cm) <i>Two included in set; product number is for one only</i>
2027-11E	[Extraction Spreader Size 3] Thread Diameter: 12-15 mm Overall Length: 2.75" (7 cm) <i>Two included in set; product number is for one only</i>
2027-12A	[Extraction Assembly Rod & Slaphammer] Overall Length: 18.5" (47 cm)
2027-12B	[Extraction Push Rod] Overall Length: 19" (48,3 cm)
2027-12C	[Extraction Tightening Assembly] Overall Length: 3" (7,6 cm) Handle Width: 2.125" (5,4 cm)
2027-CASE	[Case] <i>Not Shown</i>

See Reverse Side
For Instructions



Extraction Spreader Size 1 // 6-9 mm
#2027-11A
Two included in set; product number is for one only



Extraction Spreader Size 1.5 // 8-10 mm
#2027-11B
Two included in set; product number is for one only



Extraction Spreader Size 2 // 9-12 mm
#2027-11C
Two included in set; product number is for one only



Extraction Spreader Size 2.5 // 11-13 mm
#2027-11D
Two included in set; product number is for one only



Extraction Spreader Size 3 // 12-15 mm
#2027-11E
Two included in set; product number is for one only



Extraction Assembly Rod & Slaphammer
#2027-12A



Extraction Push Rod
#2027-12B



Extraction Tightening Assembly
#2027-12C

MADE FOR INNOVATION IN
GERMANY

www.innomed.net



ISO 13485:2016

FREE TRIAL ON MOST INSTRUMENTS

INNOMED



103 Estus Drive, Savannah, GA 31404
info@innomed.net

912.236.0000 Phone
912.236.7766 Fax

Innomed-Europe Tel. +41 41 740 67 74
info@innomed-europe.com

1.800.548.2362

Intramedullary Nail Removal Set

INSTRUCTIONS FOR NAIL REMOVAL:

- 1 Insert the push rod into the slaphammer rod, leaving the ball end outside of the slaphammer rod. Connect the t-handle tightening assembly over the ball end of the push rod. Screw the t-handle tightening assembly with push rod attached into the slaphammer rod.
- 2 To determine the correct size of nail extraction spreader, it should be completely inside the nail to be removed. If the extraction spreader wobbles, then it is too small. If threads are exposed, it is too large.
- 3 The extraction spreader is then completely threaded into the tapered end of the slaphammer rod. It is tightened using the open-end wrench and stabilizing bar.
- 4 The complete assembly is screwed into the nail by hand tightening.
- 5 Tap on the end of the t-handle tightening assembly with three light taps and re-tighten the t-handle tightening assembly if needed. Using the slaphammer or mallet, start with light taps to remove the nail.

